

## ***JPoint Mounting Adapter Installation Instructions: Scope-top secondary sight system***

### ***Parts Included:***

- JPoint mounting adaptor
- Two (2) 6-32 x 3/8" button socket cap screws
- One (1) tube Loctite 380

---

### ***Installation Instructions***

***CAUTION: REMOVE MAGAZINE AND VISUALLY CHECK CHAMBER TO MAKE SURE THAT FIREARM IS UNLOADED.***

Before beginning the installation of this JPoint mount, note that it is relieved on one end to clear a scope ring assuming that you mount the adapter to the rear of the turret (as shown below) and have typical spacing of your rings. However, you may mount the adapter anywhere you see fit, as eye relief on the JPoint is not a concern. It could be forward of the turret or mounted to the side at a 90° angle for that matter. Side mounting would reverse your elevation/windage adjustments, of course. When mounting, it is normally adequate to eyeball the adapter level to the scope turret cap. Be aware also that the mount has four screw holes allowing the mount to be reversed for added versatility.

To install the mount, first check the bottom edge of the radius for burrs that may prevent it from fitting flush on the scope tube. In order to allow maximum surface area in contact with the scope tube, the mount comes to a knife-edge at the bottom, which is easily deformed. A burr or ding on this edge will prevent the adhesive from bonding to the scope tube and must be removed with a file or deburring tool. Once attached, a full-contact bond with the supplied Loctite 380 will tolerate a considerable amount of recoil. Loctite 380 is a cyanoacrylate superglue that is shock and heat resistant and will tightly bond the mount to the scope. If you have a matte finish scope, no surface preparation other than degreasing is necessary. However, if your scope is highly polished, we recommend abrading the mounting surface with Scotchbrite™, or medium sandpaper to allow for better bonding of the adhesive. Also, be sure to degrease the bottom of the block before proceeding.

To attach the mount, first position the adapter and using a marking pen, outline it on the top of the scope tube. Then, mask the surrounding area with tape and when you are ready, use the supplied Loctite to glue the block to the scope. The set time for the adhesive is very short, about 20 seconds, so be sure to do a trial positioning before using the glue.



***THANKS FOR YOUR BUSINESS!***