

## ***JP Benchrest Stock Conversion Kit***

### ***Parts Included:***

- Stock
- Cross brace bar installed in stock
- Modified pistol grip
- Swivel stud
- One (1) ¼-28 x 1¼" button standard cap screw
- One (1) 12-24 x 1½" flat head cap screw
- Aluminum backer plate

---

***CAUTION: REMOVE MAGAZINE AND VISUALLY CHECK CHAMBER TO MAKE SURE THAT FIREARM IS UNLOADED.***

To install this assembly on a lower that has an existing A2 stock and pistol grip, first remove the pistol grip being careful not to lose the safety detente and spring. Remove the new modified grip from the cross brace on the JP stock and install it with the safety detente and spring in place. Then, remove the existing stock, taking care not to lose the takedown detente spring, which will protrude from the back of the lower receiver. Remove the butt plate assembly from the original stock and replace the lower stock screw with the one provided in the JPBR5 stock kit. You may eliminate the buttstock spacer and then install the JPBR5, inserting the cross brace rod into the hole in the pistol grip. Reattach the butt plate assembly and secure the grip cap. You may choose to cut off the sling swivel and drill out the stud to adapt it to the common quick-detach style sling swivels.

***THANKS FOR YOUR BUSINESS!***